28

DART AEROSPACE LTD	Work Order:	19365		
1		***		
Description: Spacepod Hardware Kit	Part Number:	K10018		
-1				
Dwg: D2174 Rev. C; D2174-041 Rev. C; D2175 Rev. C	Qty:	り Kits		
¥ 03.04.30		Page 1 of 2		

Step	Location	Procedure	Ву	Date	Qty
1	DC \	Issue Traveler	T		
		Note: K10018 Kit to be made in multiples of 7.	1,1		_
		(1) K10018 requires (2) D2174-041.	IKH	03.06.30	1
1		(1) D2174-041 consists of (1) D2174-1 Web & (2) D2175 Angle	1'77		<i>'</i>
2	MV	Cut blanks: (12.000" x 3.850")			
_]	Material: 2024-T3 (QQ-A-250/5) 0.063" thick sheet		,	
		(M2024T3S.063) Use stack of 7		1 1	
1		Identify for D2174-1 Batch:			
3	MV	Cut (2) blanks per (1) K10018 Kit	 	7	
3	1010	Cut blanks: (12.200" x 2.960") grain along 2.960	ł	/	
}		Material: 2024-T3 (QQ-A-250/5) 0.063" thick sheet	1		
		(M2024\(3\)S.063) Use stack of 7			
	,	Identify for D2175 Batch:			
4	MV		-		
4	IVIV	Machine D2174-1 as per Folio FA097 and Dwg D2174-1			
	000	Identify as D2174-1	 		
5	QC2	Inspect parts as they come off the CNC machine			
	3.07	Debugge			
6	MV	Deburr for measurement			
7	000	Second check			
7	QC8	Second check		\	
8	MV	Machine D2175 as\per Folio FA083 and Dwg D2175			
		Identify as D2175		_ / /	
9	QC2	Inspect parts as they come off the CNC machine		. /	
					11
10	MV	Deburr for measurement		A T 1//	
			\		1
11	QC8	Second check		M + M)
12	GA	Deburr D2174-1 and D2175 stacks			
		`\\		V	
13	GB	Form D2175 Angle as per Dwg D2175		, l	
		<u> </u>			
14	QC5	Inspect work to Step 13			
			L		
15	FP	Chemical Conversion Coat per QSI 005 4.1 and Dwg D2174-1			
- 40		and D2175			
16	QC3	Inspect work to Step 15			
47		Accombio D0474 4 and D0475 and D0474 044			
17	GA	Assemble D2174-1 and D2175 as per Dwg D2174-041			
		Pick:			
	ļ	Qty Part Number Description Batch			
	j	23 MS20470AD4-6 Rivet			
-10	005	Identify as D2174-041			
18	QC5	Inspect work to Step 17			
19	FP	Powder Coat White (Ref: 4.3.5.1) as per QSI 005 4.3			
וש	15	rowder Coal Wille (Rel. 4.3.3.1) as per Q31003 4.3			
20	QC3	Inspect Powder Coat. Go to KP cell for packing.			
20	QUS	inspect Fowder Coat. Go to NF cell for packing.		L	

Dart Aerospace Ltd

Work Order:		V						
DATE	STEP	PROCE	DURE CHANGE	Ву	Date	Qty	Approval Manuf / Design Mgr	Approval QC Inspector
		-						
NCR		V	VORK ORDER NON-CONFOR	MANCE				
DATE	STEP	Description of NC section A	Corrective Action Section B	Sign & Date	Verif Sec	ication ction C	Approval Design Mgr	Approval QC Inspector
·								
		· · · · · · · · · · · · · · · · · · ·					•	
	1	PAR#:	Fault Category:		۸٠		Date:	1

NOTE: Date & initial all entries H:Admin-QA\ISO\forms\w/oncB.doc

QA: N/C Closed: ____ Date:___

DART AEROSPACE LTD	Work Order:	
Description: Spacepod Hardware Kit	Part Number:	K10018
Dwg: D2174 Rev. C; D2174-041 Rev. C; D2175 Rev. C	Qty:	Kits
PF03.04.30		Page 2 of 2

Step	Location	Procedure	Ву	Date	Qty
21	KP	Pick: Packing Kit (Note: D2174-041 is not on the BOM, but is in as material from steps 2 & 3) Oty Part Number Description 2 D2174-041 Web Assembly B B 13733 1 D2985 Decal B 14160 8 A3235-020-935 Washer	SB	03.07.02	7
22	QC4	Inspect Kit 100% for Completeness on the W/O	0	03-07-02	1.
23	ST	Identify and Stock	SB	22:07:07	7
24	AC	Cost / part 61.26	548	03-07-03	7
25	DC	Close W/O 6/30 Inspect Level 21	B	63.61.03	

Rev	Date	Change	Revised By	Approved
Α	03.03.26	New issue	KJ/RF* 2	<u> </u>




Dart Aerospace Ltd

Work		WORK ORDER CHANGES							
Order:					Ву	Date			
DATE	STEP	PROCEDU	PROCEDURE CHANGE				Qty	Approval Manuf / Design Mgr	Approval QC Inspector
NCR		We	ORK O	RDER NON-CONFORM	ANCE				
DATE	STEP	Description of NC section A	Intial	Corrective Action Section B	Sign & Date		ication ction C	Approval Design Mgr	Approval QC Inspector
							-		
			į				ļ		
	J	PAR#:		Fault Category:	DQ	A:		Date:	


NOTE: Date & initial all entries H:Admin-QA\ISO\forms\w/oncB.doc


QA: N/C Closed: _____ Date:____





DESIGN DRAWN BY DART **AEROSPACE** LTD **B WILLIAMS** K HAND VICTORIA INTERNATIONAL AIRPORT, CANADA APPROVED CHECKED DRAWING NO. REV. BO D2174-1 SHEET 1 OF 1 DATE TITLE SCALE 95:10:25 **WEB**






Copyright 1995 by DART AEROSPACE LTD

01.02.22

ADD HOLE

DIMENSIONS



DESIGN

Job Costing Report

Dart Aerospace Ltd. Hawkesbury

Jul 01, 2003 10:58 am

Work Order No : 0019365
Project Name : K10018
Project For : WK328

Work Order Type : Main

Main WO Number :

House Part Number: K10018

Description : Spacepod Hardware Kit Invoice Number :
Manufactured : Yes Invoice Amount : 0.00

Manufactured : Yes

Amount Req'd: 7
Amount Done: 0
Start Date: 07-01-03

Est Finish Date : 07-05-03

Act Finish Date : Drawings Reqd : No

Approval Rec'd :

Ok for Approval :

Department Code: Burden Flags : Burden Flags : NNNNNNN WO Status : Open

Invoice State : Not Invoiced

Invoice Date :

Order Entry No :
OE Value : 0.00

Est Margin : 0.000% Actual Margin : 0.000%

\$0 Posted to Finished Goods

		Estimated	Actual	Var. %	Posted	To Post
Material Cost	==	0.00	0.00	0.00	0.00	0.00
Engineering Hours	:	0.00	0.00	0.00		
Engineering Cost	:	0.00	0.00	0.00	0.00	0.00
Production Hours	:	0.00	0.00	0.00		
Production Cost	:	0.00	0.00	0.00	0.00	0.00
Testing Hours	:	0.00	0.00	0.00		
Testing Cost	:	0.00	0.00	0.00	0.00	0.00
OverHead Hours	:	0.00	0.00	0.00		
OverHead Cost	:	0.00	0.00	0.00	0.00	0.00
SubContract Hours	:	0.00	0.00	0.00		
SubContract	:	0.00	0.00	0.00	0.00	0.00
Misc. Hours	:	0.00	0.00	0.00		
Misc.	:	0.00	0.00	0.00	0.00	0.00
•		========	========	======		
Burden	:	0.00	0.00	0.00		
		=======	========	======		
Total Cost	:	0.00	0.00	0.00		
Margin	:	0.000	0.000			
Selĺing Cost	:	0.00	0.00			

Estimated Actual 0.00 Labour Hrs/Amount Done : 0.00
Profits/(Loss) : 0.00 0.00 Profits/(Loss) :